



WREN TORQUE WRENCHES - Hex Cassette

Torque Conversion Chart - PSI Pressure to Torque

PSI	Low 2		Low 4		Low 8		Low 14		Low 30	
	Ft Lbs	NM	Ft Lbs	NM	Ft Lbs	NM	Ft Lbs	NM	Ft Lbs	NM
1500	220	298	632	857	1037	1406	1775	2407	3839	5205
1600	235	319	705	956	1110	1505	1899	2575	4123	5590
1800	267	362	778	1055	1257	1704	2144	2907	4693	6363
2000	298	404	850	1152	1403	1902	2390	3240	5262	7134
2200	330	447	935	1268	1547	2097	2637	3575	5845	7925
2400	361	489	1020	1383	1690	2291	2883	3909	6428	8715
2600	393	533	1105	1498	1833	2485	3130	4244	7011	9506
2800	424	575	1190	1613	1977	2680	3376	4577	7594	10296
3000	456	618	1273	1726	2120	2874	3623	4912	8177	11086
3200	488	662	1358	1841	2265	3071	3873	5251	8757	11873
3400	520	705	1443	1956	2410	3267	4124	5591	9337	12659
3600	552	748	1528	2072	2555	3464	4374	5930	9916	13444
3800	585	793	1613	2187	2700	3661	4625	6271	10496	14230
4000	617	837	1698	2302	2852	3867	4876	6611	11076	15017
4200	648	879	1786	2421	2991	4055	5130	6955	11666	15817
4400	680	922	1874	2541	3137	4253	5383	7298	12255	16615
4600	711	964	1962	2660	3284	4452	5638	7644	12845	17415
4800	743	1007	2050	2779	3430	4650	5892	7988	13434	18214
5000	774	1049	2137	2897	3576	4848	6146	8333	14024	19014
5200	807	1094	2223	3014	3723	5048	6405	8684	14618	19819
5400	840	1139	2309	3131	3870	5247	6665	9036	15212	20624
5600	874	1185	2395	3247	4018	5448	6925	9389	15806	21430
5800	907	1230	2481	3364	4165	5647	7185	9741	16400	22235
6000	940	1274	2565	3478	4312	5846	7445	10094	16994	23040
6200	972	1318	2654	3598	4465	6054	7700	10440	17591	23850
6400	1004	1361	2743	3719	4619	6262	7955	10785	18187	24658
6600	1036	1405	2832	3840	4773	6471	8211	11132	18784	25467
6800	1068	1448	2921	3960	4926	6679	8466	11478	19380	26275
7000	1100	1491	3008	4078	5080	6887	8721	11824	19977	27085
7200	1133	1536	3094	4195	5223	7081	8977	12171	20569	27887
7400	1166	1581	3180	4311	5367	7277	9233	12518	21161	28690
7600	1199	1626	3266	4428	5510	7470	9488	12864	21752	29491
7800	1232	1670	3352	4545	5654	7666	9744	13211	22344	30294
8000	1265	1715	3436	4659	5723	7759	10000	13558	22936	31097
8200	1298	1760	3524	4778	5954	8072	10255	13904	23528	31899
8400	1330	1803	3612	4897	6111	8285	10509	14248	24120	32702
8600	1362	1847	3700	5016	6267	8497	10764	14594	24712	33505
8800	1395	1891	3788	5136	6424	8710	11018	14938	25304	34307
9000	1427	1935	3877	5256	6581	8923	11273	15284	25896	35110
9200	1459	1978	3961	5370	6730	9125	11517	15615	26489	35914
9400	1489	2019	4045	5484	6880	9328	11760	15944	27082	36718
9600	1521	2062	4129	5598	7029	9530	12003	16274	27675	37522
9800	1552	2104	4213	5712	7178	9732	12247	16604	28268	38326
10000	1590	2156	4300	5830	7320	9924	12500	16948	28861	39130

Hire Torque Tools Victoria Ph: 0468 345 078 ~ Hire & Sales ~

(Disclaimer: Use included data at own risk)

www.hiretorquetoolsvictoria.com.au ~ Email: info@hiretorquetoolsvictoria.com.au